

NIAWAVE

Niacinamide PC for a new wave of beauty



NIAWAVE

Niacinamide PC for
a new wave of beauty

Aging brings its own set of challenges, but it also has the power to unlock new opportunities for a more fulfilling life. Embrace the beauty of maturity with **NIAWAVE**.

NIAWAVE is a skincare line crafted to cater your skin's evolving needs and to honour your powerful beauty.

Recent scientific studies on pre and post-menopausal skin highlight the pivotal role of Niacinamide PC in addressing menopausal skin changes. This potent ingredient helps prevent photoaging, boosts collagen production, reduces inflammation, and minimizes sensitivity to daily stressors, promoting healthy aging.

For skin that is stronger, more resilient,
and radiant, just like you.

NIAWAVE

Niacinamide PC for
a new wave of beauty



Products are for illustration only, not for sale.
dsm-firmenich is not responsible for final product claims.

dsm-firmenich 

NIAWAVE

Niacinamide PC for
a new wave of beauty

BRIGHT ENERGY SERUM

With a powerful combination of Niacinamide PC and vitamins B5, C, and E, our facial serum is perfect for maintaining radiant, even-toned skin at every stage of life. It helps control hyperpigmentation, energizes the skin, and restores its glow and vitality during the challenges of menopause. Plus, it reduces signs of aging, helping you look youthful and face hormonal changes with greater confidence.



dsm-firmenich 

Products are for illustration only, not for sale.
dsm-firmenich is not responsible for final product claims.

NIAWAVE

BRIGHT ENERGY SERUM

93,41% Natural Origin content according to ISO 16128



PHASE	INGREDIENTS	INCI NAME	% W / W
A	Water Dem	AQUA	59,00
	STAY-C® 50	SODIUM ASCORBYL PHOSPHATE	3,00
	Niacinamide PC	NIACINAMIDE	3,00
	SODIUM METABISULFITE	SODIUM METABISULFITE	0,10
	D-PANTHENOL	PANTHENOL	1,00
	Edeta® BD	DISODIUM EDTA	0,10
B	Glycerin 99.5%	GLYCERIN	5,00
	Propanediol	PROPANEDIOL	25,00
	HYA-ACT™ M	SODIUM HYALURONATE	0,20
C	DL-alpha-Tocopheryl Acetate	TOCOPHERYL ACETATE	0,10
	Focusguard PE 9010	PHENOXYETHANOL, ETHYLHEXYLGLYCERIN	0,60
	PEG-40 HYDROGENATED CASTOR OIL	PEG-40 HYDROGENATED CASTOR OIL	1,20
	RB-211127 Facial 2	PARFUM	0,50
D	Citric Acid 25% solution	AQUA, CITRIC ACID	1,20

SK-E-103204-1

PROCEDURE:

- 1 Prepare Phase A and stir until it's homogenous.
- 2 Add Phase B under stirring, until it's homogenous.
- 3 Add Phase C as a premix and homogenize under stirring.
- 4 Adjust pH with Phase C

TECHNICAL DATA:

pH: 7,3 Viscosity: < 100 mPa.s

Technical Specificity: Opalescent

The formulation fulfils the 3 months stability at 4°C, room temperature, 40°C

The information provided herein is provided for information purposes only and has been prepared by dsm-firmenich in accordance with its own methodology. dsm-firmenich has used diligent care to ensure that it is accurate and up to date, however, dsm-firmenich makes no representation or warranty, either expressly or implied, of the accuracy, reliability, or completeness thereof. In no event shall dsm-firmenich be liable for any damages arising from or reliance upon, or use of, any information provided herein. Further, dsm-firmenich shall not bear any liability for the application and/or use of any processed material containing its product(s). The formulation of the finished product is the customer's sole responsibility. It is the customer's responsibility to determine the suitability of dsm-firmenich's products regarding user specific purposes, assess compatibility and stability of their finished product(s) and to ensure compliance of their finished product(s) with relevant laws and regulations. Any product, marketing or other claims made by customer are its sole responsibility. The content of this document is subject to change without further notice. Please contact your local dsm-firmenich representative for further details. © DSM Nutritional Products AG, 2024

dsm-firmenich 

NIAWAVE

Niacinamide PC for
a new wave of beauty

BALANCING FACIAL CREAM

Our facial cream is your perfect partner for your skincare routine during menopause! With Niacinamide PC and vitamins B5, B6, and B12, it restores ceramide balance, strengthens the skin's barrier, and delivers deep hydration. It also stimulates collagen production, while smoothing out fine lines and wrinkles, combating dryness and sensitivity that often accompany this life stage. Best of all, it protects against environmental stress and hormonal changes, leaving you looking radiant and full of vitality.



dsm-firmenich 

Products are for illustration only, not for sale.
dsm-firmenich is not responsible for final product claims.

NIAWAVE

BALANCING FACIAL CREAM



PHASE	INGREDIENTS	INCI NAME	% W / W
A	Water Dem	AQUA	78,49
	Ecogel™	LYSOLECITHIN, SCLEROTIUM GUM, PULLULAN, XANTHAN GUM	2,50
	Propanediol	PROPANEDIOL	3,00
	Dermosoft® Octiol	CAPRYLYL GLYCOL	0,20
	Cosphaderm® Pentiol natural	PENTYLENE GLYCOL	3,00
B	Myritol® 318	CAPRYLIC/CAPRIC TRIGLYCERIDE	5,00
	Perfume Fleur de peau RS90514	PARFUM	0,15
C	VALVANCE® Touch 210	SILICA	1,00
D	Niacinamide PC	NIACINAMIDE	4,00
	D-Panthenol 75 L	PANTHENOL, AQUA	2,00
	PYRIDOXINE HYDROCHLORIDE (VITAMIN B6)	PYRIDOXINE HCL	0,20
	Vitamin B12 Cryst Food Grade	CYANOCOBALAMIN	0,01
E	Sodium Hydroxide 10% Solution	AQUA, SODIUM HYDROXIDE	0,45

SK-E-103205-1

PROCEDURE:

- 1 Prepare Phase A and heat up to 75°C–80°C under stirring for 30 min.
- 2 Prepare Phase B under stirring.
- 3 Add Phase B into Phase A under stirring.
- 4 Add Phase C into Phase A+B and homogenize at 18000 rpm for 2 min.
- 5 Cool down to 35°C under stirring.
- 6 Add ingredients of Phase D one by one into the emulsion under stirring.
- 7 Adjust pH to 7 with Phase E.

TECHNICAL DATA:

pH: 7,2 Viscosity (spindle RV-4 / 10 rpm): 8640 mPa.s

Technical Specificity: Opaque

The formulation fulfils the 3 months stability at 4°C, room temperature, 40°C, 50°C and daylight

dsm-firmenich 

The information provided herein is provided for information purposes only and has been prepared by dsm-firmenich in accordance with its own methodology. dsm-firmenich has used diligent care to ensure that it is accurate and up to date, however, dsm-firmenich makes no representation or warranty, either expressly or implied, of the accuracy, reliability, or completeness thereof. In no event shall dsm-firmenich be liable for any damages arising from or reliance upon, or use of, any information provided herein. Further, dsm-firmenich shall not bear any liability for the application and/or use of any processed material containing its product(s). The formulation of the finished product is the customer's sole responsibility. It is the customer's responsibility to determine the suitability of dsm-firmenich's products regarding user specific purposes, assess compatibility and stability of their finished product(s) and to ensure compliance of their finished product(s) with relevant laws and regulations. Any product, marketing or other claims made by customer are its sole responsibility. The content of this document is subject to change without further notice. Please contact your local dsm-firmenich representative for further details. © DSM Nutritional Products AG, 2024

NIAWAVE

Niacinamide PC for
a new wave of beauty

PROTECT & REPAIR STICK RADIANT SHIELD

Looking for an easier way to protect your skin from daily sun damage? Check out our powerful stick! Enriched with Niacinamide PC (2.5%), it offers superior UV protection with the super trio of PARSOL® UV filters while boosting your skin's natural repair against sun damage. It prevents photoaging and leaves your skin healthy and glowing like the sun itself!



dsm-firmenich 

Products are for illustration only, not for sale.
dsm-firmenich is not responsible for final product claims.



The information provided herein is provided for information purposes only and has been prepared by dsm-firmenich in accordance with its own methodology. dsm-firmenich has used diligent care to ensure that it is accurate and up to date, however, dsm-firmenich makes no representation or warranty, either expressly or implied, of the accuracy, reliability, or completeness thereof. In no event shall dsm-firmenich be liable for any damages arising from or reliance upon, or use of, any information provided herein. Further, dsm-firmenich shall not bear any liability for the application and/or use of any processed material containing its product(s). The formulation of the finished product is the customer's sole responsibility. It is the customer's responsibility to determine the suitability of dsm-firmenich's products regarding user specific purposes, assess compatibility and stability of their finished product(s) and to ensure compliance of their finished product(s) with relevant laws and regulations. Any product, marketing or other claims made by customer are its sole responsibility. The content of this document is subject to change without further notice. Please contact your local dsm-firmenich representative for further details. © DSM Nutritional Products AG, 2024

NIAWAVE

PROTECT & REPAIR
STICK RADIANT SHIELD

PHASE	INGREDIENTS	INCI NAME	% W / W
A	UVA-sorb HEB	DIETHYLHEXYL BUTAMIDO TRIAZONE	3,00
	Cetiol® B	DIBUTYL ADIPATE	10,00
B	PARSOL® DHHB	DIETHYLAMINO HYDROXYBENZOYL HEXYL BENZOATE	9,50
	PARSOL® EHT	ETHYLHEXYL TRIAZONE	2,50
	PARSOL® Shield	BIS-ETHYLHEXYLOXYPHENOL METHOXYPHENYL TRIAZINE	5,00
	Finsolv® TN	C12-15 ALKYL BENZOATE	15,00
	Cetiol® CC	DICAPRYLYL CARBONATE, TOCOPHEROL	10,00
	Eutanol® G 16	HEXYLDECANOL	9,70
	KahlWax 2811 Rice	ORYZA SATIVA BRAN CERA	9,50
	KahlWax 2225 Phyto	HELIANTHUS ANNUUS SEED CERA, OLEA EUROPAEA OIL UNSATURATED, RHUS VERNICIFLUA PEEL CERA, SHOREA ROBUSTA RESIN	5,00
	KahlWax 6642 Organic Carnauba	COPERNICIA CERIFERA CERA	3,50
	antaron™ soja glyceride	MALEATED SOYBEAN OIL GLYCERYL/OCTYLDODECANOL ESTERS	2,00
	Mixed Tocopherols 95	TOCOPHEROL	0,20
	DL-alpha-Tocopheryl Acetate	TOCOPHERYL ACETATE	0,50
	Eldew SL-205	ISOPROPYL LAUROYL SARCOSEINATE	2,40
C	Niacinamide PC	NIACINAMIDE	2,50
	Water Dem	AQUA	4,99
	Vitamin B12 cryst Food Grade	CYANOCOBALAMIN	0,01
	SODIUM GLUCONATE GRANULAR	SODIUM GLUCONATE	0,40
D	ACTICIRE MB	JOJOBA ESTERS, ACACIA DECURRENS FLOWER CERA, HELIANTHUS ANNUUS SEED CERA, POLYGLYCERIN-3	4,00
	GLACIAL CASCADE CHBG-2587/15	PARFUM, CITRONELLOL, HEXYL CINNAMAL	0,30

SU-E-103209-1

PROCEDURE:

- 1 Prepare Phase A and heat up to 90°C under stirring until homogeneous.
- 2 Prepare Phase B and add it to Phase A.
- 3 Heat Phase A+B to 90°C under stirring until homogeneous.
- 4 Prepare Phase C and heat up to 60°C under stirring until homogeneous.
- 5 Prepare Phase D and add it into Phase C under stirring until homogeneous.
- 6 Cool down Phase A+B to 80°C.
- 7 Add Phase C+D into Phase A+B under stirring.
- 8 Cool down to 75°C.
- 9 Pour into the mold.

TECHNICAL DATA:

pH:	7,2		
Viscosity :	Solid		
Technical Specificities:	Stick, Opaque		
SPF:	64,8	In vitro UVA-PF:	21,4
In vivo according to ISO 24444		According to ISO 24443	
UVA-PF/SPF:	0,35	Critical Wavelength:	373 nm
(60 labelled; >= 0.33)		(Measurement done with Labsphere equipment)	

The formulation fulfils the 2 weeks stability at 50°C and the 3 months stability at 4°C, room temperature, 40°C. Regulatory compliance in EU, MERCOSUR, ASEAN, CN, KR, AUS for UV filters in formulation.

dsm-firmenich

NIAWAVE

Niacinamide PC for
a new wave of beauty

HYDRASTRENGTH HAIR DROPS

A few drops, many benefits! This advanced formula hair serum combines the power of Niacinamide PC (0.5%) with other ingredients to provide complete and sophisticated care for menopausal women's hair and scalp. It boosts thickness, volume, and strength while keeping the scalp hydrated, leaving your hair healthier, stronger, and full of vitality.



dsm-firmenich 

Products are for illustration only, not for sale.
dsm-firmenich is not responsible for final product claims.



NIAWAVE

HYDRASTRENGTH HAIR DROPS

98.80% Natural Origin content according to ISO 16128

PHASE	INGREDIENTS	INCI NAME	% W / W
A	Water Dem	AQUA	77,16
	Natrosol 250 HR PC	HYDROXYETHYLCELLULOSE	1,00
B	D-Biotin	BIOTIN	0,02
	PENTAVITIN®	SACCHARIDE ISOMERATE, AQUA, CITRIC ACID, SODIUM CITRATE	0,80
	Niacinamide PC	NIACINAMIDE	0,50
	SODIUM GLUCONATE GRANULAR	SODIUM GLUCONATE	0,20
	ALPAFLOR® EDELWEISS CB	LEONTOPODIUM ALPINUM FLOWER/LEAF EXTRACT, GLYCERIN, AQUA, CITRIC ACID	1,00
	Vitamin B12 cryst Food Grade	CYANOCOBALAMIN	0,02
	ALPAFLOR® ALP-SEBUM CB	EPILOBIUM FLEISCHERI FLOWER / LEAF / STEM EXTRACT, GLYCERIN, AQUA, CITRIC ACID	1,50
	Propanediol	PROPANEDIOL	5,00
C	ALCOHOL DENAT.	ALCOHOL DENAT.	12,00
	U Locks P01B839	PARFUM, COUMARIN, HEXYL CINNAMAL, BENZYL SALICYLATE, D-LIMONENE, ALPHA-ISOMETHYL IONONE, HYDROXYCITRONELLAL	0,40
	ARGAN OIL	ARGANIA SPINOSA KERNEL OIL	0,10
	Dermosoft Hexiol	1,2-HEXANEDIOL	0,30

HC-E-102436-15

PROCEDURE:

- 1 Prepare Phase A by adding ingredients in water and stir until a homogeneous solution is obtained.
- 2 Prepare ingredients of Phase B and slowly pour into Phase A under stirring.
- 3 Prepare ingredients of Phase C one by one and add into Phase A+B under stirring.

TECHNICAL DATA:

pH: 4.9 Viscosity (HR-10/ plate 40mm/ shear rate 1/s): 1200 mPa.s

Technical Specificity: Opalescent

The formulation fulfils the 3 months stability at 4°C, room temperature, 40°C

The information provided herein is provided for information purposes only and has been prepared by dsm-firmenich in accordance with its own methodology. dsm-firmenich has used diligent care to ensure that it is accurate and up to date, however, dsm-firmenich makes no representation or warranty, either expressly or implied, of the accuracy, reliability, or completeness thereof. In no event shall dsm-firmenich be liable for any damages arising from or reliance upon, or use of, any information provided herein. Further, dsm-firmenich shall not bear any liability for the application and/or use of any processed material containing its product(s). The formulation of the finished product is the customer's sole responsibility. It is the customer's responsibility to determine the suitability of dsm-firmenich's products regarding user specific purposes, assess compatibility and stability of their finished product(s) and to ensure compliance of their finished product(s) with relevant laws and regulations. Any product, marketing or other claims made by customer are its sole responsibility. The content of this document is subject to change without further notice. Please contact your local dsm-firmenich representative for further details. © DSM Nutritional Products AG, 2024

dsm-firmenich

NIAWAVE

Niacinamide PC for a new wave of beauty